

How To

Please follow instructions carefully and remember the better your template, the better the finished product will be.

1. Lay plastic film or butcher paper over area to be templated, using scissors trim film slightly larger than the area to be templated.
2. Use masking tape to secure the film or paper in place so it will not move during template process.
- 3A. (Non Skid Method) Use pen or permanent marker to trace a line .25" inches around the outside of the entire factory non skid area. This provides enough space for the material to create a watertight seal outside of the non-skid.
- 3B. (Smooth Surface Method) Use pen or permanent marker to draw a line of the desired area.

Use a small straight edge or ruler to produce a cleaner template.

4. Please number each part. (See #4 on diagram of next page)
5. Please draw an Arrow on each part pointing toward the Front/Bow.
(See #5 on diagram of next page)
6. Please identify the top of all parts and their location on your boat.
Example: Top, Floor, Port, - Top, Floor, Center - Top, Floor Starboard (See #6 on diagram of next page)
7. Please identify areas with holes or hinges that need to be cut out. (See #8 on diagram of next page)
8. To add a logo, please write "Logo Here" on desired part. (See #8 on diagram of next page)
9. Draw a few line up lines between parts for proper placement in the design process.
(See #9 on diagram of next page)
10. Write your name, phone number, email, boat make, model, year and color choices on at least one part for our reference. (See #10 on diagram of next page)
11. DO NOT cut film or paper to the lines you have drawn. We need the extra space for digitizing.
12. Take photos of each traced part before removing them from your boat.
13. See diagrams on next page for explanations of above.